Kolcraft Cloud Plus "Free-Stand" Button Replacement

This guide will demonstrate how to open, access, and replace the “Free-Stand” button on the Kolcraft Cloud Plus.

Written By: Christopher Peterson



INTRODUCTION

The “Free-Stand” button enables the stroller to fold into a freestanding, compact position. Sometimes the button can get stuck and requires simple internal repair. This guide will walk you through that process.

TOOLS:

- Phillips #2 Screwdriver (1)
- Magnetic Project Mat (1)

Step 1 — "Free-Stand" Button





- Unscrew the two, 27mm Phillips #2 screws from the back of the “Free-Stand” button case.

ⓘ You may want to flip the stroller over to access the screws.

Step 2



- Remove the back cover of the case by lifting it straight up.

Step 3



⚠ The spring may pop out while removing the "Free Stand" button, so lift the button slowly to avoid losing the spring.

- To access the spring, remove the red, "Free-Stand" button by lifting it straight up.

Step 4



- If the spring does not come out when you remove the "Free-Stand" button, lift the spring out of the case so it can be fixed or replaced.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-12 01:27:50 PM.